


Quartus information:




Set up information:




Select ok




Built circuit




Processing -> Start -> Start Analysis & Elaboration (Normally I don't do this, instead I just use Processing -> Start Compilation)




Assignments -> Pin Planner (This is where the problem is, I can't see the two inputs or the output.)



Processing -> Start Compilation (I thought I'd give this a try since this is what was used in QuartusII which worked in the past.)



Assignments -> Pin Planner



I scrolled throght the Node Name list and did not find the inputs or output listed.