



Installation USB Blaster II driver on Windows 10

By: ShafiqY


1. Search **"This PC"** > right click > properties >
2. Click on **Device Manager**.
3. Right click on **USB-Blaster** > click on **Update driver**




4. Click on **"Browse my computer for driver software"**




5. Search to **C:\intelFPGA_pro\19.4\qprogrammer\quartus\drivers\usb-blaster-ii\x64**




6. Click Next
7. Unable to install




8. Right click on **USB-Blaster** > click on **Update driver**



9. Click on “**Browse my computer for driver software**”



10. Search to **C:\intelFPGA_pro\19.4\qprogrammer\quartus\drivers**



11. Successfully installed

