

Settings

General

- System Information
- Battery Information
- Boot Sequence
- UEFI Boot Path Security
- Date/Time

System Configuration

- Integrated NIC
- SATA Operation**
- Drives
- SMART Reporting
- USB Configuration
- Thunderbolt™ Adapter Configuration
- USB PowerShare
- Audio
- Keyboard Illumination
- Keyboard Backlight Timeout on AC
- Keyboard Backlight Timeout on Battery
- Unobtrusive Mode
- Fingerprint Reader
- Miscellaneous Devices
- MAC Address Pass-Through

Video

- Security
- Secure Boot
- Intel® Software Guard Extensions™
- Performance
- Power Management
- POST Behavior
- Manageability
- Virtualization Support
- Wireless
- Maintenance
- System Logs
- About
- SupportAssist System Resolution

SATA Operation

- ☐ Disabled
- ☐ AHCI
- ☒ RAID On

This option configures the operating mode of the integrated SATA hard drive controller.

Disabled = The SATA controllers are hidden.
AHCI = SATA is configured for AHCI mode.
RAID On = SATA is configured to support RAID mode (Intel® Rapid Restore Technology).

Restore Settings

Apply

Exit